

---

Subject: Bluetooth not plugged in

Posted by [Jzinsky](#) on Wed, 16 Mar 2005 21:15:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I've followed the instructions to plugging in the bluetooth port onto my motherboard (the port came with it) installed the software and it tells me the cable is unplugged. The next part of the problem is that the cable has 8 pins, whereas the board has 6. If I plug it in any other way than the way it is now, it whines (I mean it actually emits a high-pitched noise) so it's the only way it can be plugged in.

Any ideas?

---