
Subject: Bypass Administrator password
Posted by [bandie63](#) on Thu, 24 Mar 2005 23:01:19 GMT
[View Forum Message](#) <> [Reply to Message](#)

in all computers there is a cable called the password jumper. (it's in the motherboard) your manual that came with the pc should tell you how to find it. it disables all clientside passwords (that i know of) while it's unplugged.

at least it's that way on my PC....
