

---

Subject: Re: Computer trouble

Posted by [Renx](#) on Sat, 07 Jan 2006 17:14:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Clear the CMOS. Turn off the power supply and unplug it, then there should be a little two-pinned jumper sitting on a set of three pins(somewhere on the mobo). Move the jumper so it is sitting on one of the pins it wasn't before, but still on two pins. Leave it for 15s, move it back, plug in and turn on the power supply. It should post fine then.

---