

---

Subject: Keyboard

Posted by [Viking](#) on Fri, 17 Mar 2006 00:00:17 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Got this new keybord cus old one crapped out.

There are button ontop of it with pictures

Here they are:

Arrow to left (says back above it)

Arrow to right (says Forward)

House(web/serch)

magnifying glass (serch)

envelope button (says mail above it)

Calculator button (says nothing above it)

the mail button opens up a e-mail program but its the wrong one and the rest do nothing how can i set them to open the programs they are obveusly ment for?

It isent nessicary to do this just thing it would be cool to do sence the buttons are there.

---