
Subject: Re: No signal being sent to monitor
Posted by [Ryu](#) on Wed, 19 Dec 2007 02:04:44 GMT
[View Forum Message](#) <> [Reply to Message](#)

Put in one card, Install OS, Install the SLI Drivers/firmware, then add the second card.

I'm pretty sure that would work.

if not, The HDD Might not be compatible (lol) and you might need to buy a new one.
