
Subject: Re: Graphics card not working
Posted by [Carrierll](#) on Tue, 15 Jul 2008 19:59:36 GMT
[View Forum Message](#) <> [Reply to Message](#)

IronWarrior wrote on Tue, 15 July 2008 20:20Try plugging the monitor into the motherboard instead of the graphic card slot.

If it works, then the problem is with the graphic card.

Or, the BIOS is set to use the internal VGA, and that setting needs to be changed to "external" or similar.
