

---

Subject: Re: Annoying problem

Posted by [danpaul88](#) on Mon, 11 Jan 2010 07:49:55 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Probably dirt on the sensors under the buttons on the mouse, if you have a compressed air can try pointing it beneath each of the buttons and giving it a quick blast.

That or buy a new mouse, they are hardly expensive... you can get a decent Logitech mouse for about £15.

---