

---

Subject: Re: Stuck at Post screen

Posted by [Caveman](#) on Sat, 14 Aug 2010 16:34:58 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

There are two 4 pin connectors. There is one with the 20pin connector and then there is a seperate one with nothing attached to it that should goto the motherboard as well. It goes top left above the CPU most of the time.

If you have done that and the only thing you've changed is the PSU then I have no idea.

Try the basics, take out all the ram, cpu and gfx and try each one by one to see if you get any further.

For some reason this post isn't being recognised. Says you're still the last poster :S

---